


URMET 1128/510



Terminals

PS	Call Common
2	Speech Line
1	Not Used
1A	Speech Line
~	AC Power
-/~	AC Power

IMPORTANT NOTE :

1) Before replacing the speech unit make note of the wires to each terminal on the existing unit (an easy way is to cut each core off leaving a piece of the insulation in place with colour visible) twist unused cores together (so you know they are not used, do not short them out).

2) Some older systems will have cable with one coloured core and a solid white core in this case mark each core with a marker or tape.

Wiring Diagram

WIRING DIAGRAM FOR DOOR UNIT Ref. 1128/510
SCHÉMA D'INSTALLATION POSTE EXTERNE Réf. 1128/510
ESQUEMAS DE CONEXION MICROALTAVOZ Ref. 1128/510
ANSCHLUBPLAN SPRECHHEINHEIT FÜR AUSSEN BN 1128/510

SC101-0858D

